



Devon IT 6000 Series (DeTOS) Thin Client Quick Start Guide

→ Unpack

Your thin client terminal is typically shipped with the following items:

1. Power Cable
2. Quick Start Guide
3. Mouse (optional)
4. Keyboard (optional)

Inspect all parts visually for damage. If anything is damaged, please contact Devon IT immediately to report the issue.

→ Setup

1. Connect a monitor to the VGA port found on the back of the unit.
2. Connect a PS/2 mouse and keyboard to their respective ports on the back of the unit.
3. Connect an Ethernet cable (RJ45) to the Ethernet port on the back of the unit and connect the other end to your network.
4. Plug in the power cord.

→ System Start

1. Press the Power Button to turn on the terminal. The boot process will take approximately 20-30 seconds, depending on the exact model and configuration of your terminal.
2. Once the boot process is finished, you will be presented with the terminal desktop and launch window. To enter the terminal SETUP, select "System → Setup" from the Launch window. The network configuration is set to DHCP by default.
3. To change the network settings, double click on the "Network" icon located on the left-hand side of the Setup window.

→ Display Settings

To change resolutions:

- From Launcher, select "System --> Setup"
- Click the "Display" icon on the left hand side of the Setup window.
- Select the desired resolution from the dropdown list named, Screen Resolution
- You may also change the color depth on this screen
- Click the Save Settings button
- Click the Quit Setup button.
- Reboot the thin client for the display settings to take affect.

→ Administrator Password

An Admin Password can be set to restrict access to the Setup screen in DeTOS.

To set the Admin Password:

1. From Launcher, select "System -> Setup"
2. Click the "Network" icon on the left-hand side of the Setup window.
3. Click the "Admin" tab along the top this screen.
4. Enter a Password in the "Admin Password" field*.
5. Re-enter the same password in the "retry" field below
6. Press the "Set" button to apply it.
7. Click Save Settings and Quit Setup.

*Note: The password must be at least 8 characters long.



→ Creating an RDP Connection

The following steps describe how to create a simple RDP connection for your terminal:

1. Select "System → Setup" from the Launch window.
2. Click the "Sessions" icon on the left-hand side
3. Double-click the connection type named, "xRDP, Window Terminal Server"
4. This will display a screen with three tabs: General, Display and Program. The General tab is selected by default.
5. In the first field called Session Name, enter a name for this RDP connection.
6. In the "WTS Address" field, enter the IP address or the fully qualified hostname (if DNS is configured) of the terminal server you wish to connect to.
7. The next 3 fields, Username, Password and Domain are optional fields. The user will be prompted for these values, if you decide to leave them blank.
8. You also have the option of launching this RDP connection automatically at the time the terminal is booted. If you would like to enable this feature, click the checkbox called "Autostart".
9. Click the "OK" button
10. You will now be returned to the Setup screen. Click the "Save Settings" button to save the RDP connection you just configured.
11. Click "Quit Setup" to close the Setup window and return to the Launch window.
12. Your new RDP connection will now be available in the Launch window.

→ Where to Go From Here

Please see the document titled, *DeTOS 6.0 Administration Manual*, for more information about configuring your 6000 series thin client terminal: http://www.devonit.com/pdfs/Detos6_Manual.pdf