



### • **Unpack**

Your Devon IT SafeBook is typically shipped with the following items:

1. Battery
2. Phone Cord
3. Power Cord

**Inspect all parts visually for damage.**

If anything is damaged, please contact Devon IT immediately to report the issue.

### • **Setup**

1. Insert the battery into the underside of the SafeBook and click into place.
2. Plug in the power cord and charge the battery. (Approximately 2 hrs)

**Note:** Disabling wireless access when not needed will save battery charge. A fully charged battery will last approximately 6 hours.

### • **System Start**

Press the Power Button to turn on the Devon IT SafeBook. The power button is located near the top of the keypad. The SafeBook boots to display a Windows XP login screen.

There are two local accounts:

- “Administrator” – The default password is “Administrator”
- “SafeBook” – The default password is “User”



Login as the local Administrator to make any system changes. The Administrator Desktop has shortcuts to frequently used admin programs and utilities.



- **Wireless Networking**

By default the wireless switch is disabled. To enable wireless connectivity, press the button located to the left of the power button. A blue indicator light should illuminate along the bottom left-hand side of the laptop. You will now be able to search for wireless access points in your vicinity just as you would with any other Windows based machine.

- **EFW Manager**

The EWF as it is known operates by providing a “shadow writing” to the system RAM. When enabled, any writes to the storage media, such as setting changes etc are written automatically in shadow mode to the RAM overlay. This allows you to make settings and changes and then test and approve them prior to committing them to the system partition.

The SafeBook is shipped with EWF in the enabled state.

The EWF manager utility helps you to Disable, Enable or Commit changes to the EWF write filter.

Click on the EWF Manager icon on the desktop or from the Start Menu | All Programs | Administrative Tools. If the user is not a member of the local administrators group a prompt for Administrator credentials will popup as shown below. Login with an account which has local administrative privileges.

If the account is authenticated the EWF manager window will open. Click on Manage EWF.

“EFW Status” shows the current status of the EWF.

To save any setup configurations or changes to the system you have to commit changes using the “EFW commit” button in the EWF Manager. Reboot the device for the command to take effect.

To disable the EWF protection you should use the “EFW Disable”.

When you are convinced that you have the right configurations you can enable EWF protection by clicking the “EFW Enable” button.

**Note:**

Reboot after every EWF Command for the command to take effect.

THE EWF Manager is accessible from the User account from Start Menu | All Programs | Administrative Tools



- **Where to Go From Here**

Please visit the XPe Resource section of our website to download User Manuals, XPe Remote Manager Software, Snap-Ins, and other useful items relating to our XPe-based terminals.

URL: [http://www.devonit.com/resources/8020C\\_xpe\\_resource.php](http://www.devonit.com/resources/8020C_xpe_resource.php)

→ **Customer Support**

Use our [web form](#) to create an inquiry ticket with Devon IT Technical Support.

URL: [http://www.devonit.com/support/support\\_request\\_form.php](http://www.devonit.com/support/support_request_form.php)

Support Center Hours: 8AM - 8PM EST, Monday through Friday

Local Phone: 610-757-4220

Toll Free: 1-800-369-7290